



01 BLDG A - SOUTH ELEVATION

SCALE: 1/8" = 1'-0"



02 BLDG A - WEST ELEVATION

SCALE: 1/8" = 1'-0"



03 BLDG A - EAST ELEVATION

SCALE: 1/8" = 1'-0"



04 BLDG A - NORTH ELEVATION

SCALE: 1/8" = 1'-0"



05 BLDG B - SOUTH ELEVATION

SCALE: 1/8" = 1'-0"



06 BLDG B - WEST ELEVATION

SCALE: 1/8" = 1'-0"



07 BLDG B - EAST ELEVATION

SCALE: 1/8" = 1'-0"



08 BLDG B - NORTH ELEVATION

SCALE: 1/8" = 1'-0"